

# Technical Data Sheet

## GLASS FIBRE WALLPAPER

### Rednet - 60081

#### Glass fibre wallpaper

#### PRODUCT DESCRIPTION

Glass fibre wallpaper is produced from high quality impregnated, pressure and extruded glass fibres. Thanks to its structure, the product is difficult to tear and resistant to accidental cuts or scratches. The natural, non-toxic glass fleece is an excellent reinforcement for walls and ceilings. This material is flame retardant.

#### APPLICATION

The wallpaper is designed primarily for the interiors of both residential and public buildings. Recommended especially for rooms with high humidity. As reinforcement on gypsum boards, concrete, gypsum, plaster and various types of building panels. As covering on ceilings, furniture, doors.

#### ADVANTAGES

- flame retardant
- durable and resistant to mechanical damage
- waterproof
- decorative designs

#### PRODUCT PARAMETERS

Material	impregnated glass fibre
Colour	white
Width, (m)	1
Length, (lim.m.)	50
Reaction to fire	B-s1-d0
Release of formaldehyde	below the detection level
Mass per unit area , (g/m <sup>2</sup> )	105 ±10%

#### PACKAGING

Quantity per palett (rolls)	Quantity per palett (m <sup>2</sup> )
44	2 200

#### STORAGE

The product should be stored in a cool, dry place between +5°C and +30°C. In covered areas, away from fire sources. Do not allow product to freeze. Shelf life: 24 months min original, closed packaging, 6 months after opening.

#### ASSEMBLY INSTRUCTIONS

The substrate should be clean, smooth, dry, degreased, non-alkaline and primed with wallpaper adhesive or other special primer. The wallpaper adhesive should be applied evenly to the dry substrate with a roller or brush, starting from the corner of the wall. Spread the adhesive on max. 2 wallpaper widths. After applying the first wallpaper strip, the next one should be butt-attached, matching the pattern. It is also possible to make the joint by double-cutting. Smooth the entire surface with a spatula or upholstery roller. Remove all air bubbles. Trim excess fabric at the edges with an upholstery knife. After the adhesive has dried thoroughly, the wallpaper can be painted with acrylic or latex paint.